



RGB888 LCD 37PIN RESET优先使用GPIO控制，GPIO不够再使用+3V3



CC0401I40R-01\_480x480\_4.0



